PROCEDURE FOR CLEANING OF STANDARD MODEL 206 PRESSURE CAVITY



CLEANING KIT (REF. KIT NO. 890254)


PRESSURE RANGES (PSIG, PSIA, PSIS)

0-200 0-300 0-500 0-750 0-1000 0-1500

0-2000

SET CONSISTS OF: 12-SCREWS (10-32 x 3/4) 12-LOCKWASHERS

TOOLS REQUIRED:
TORQUE WRENCH-IN./LBS.
HEX SOCKET-3/16"
METHYLENE CHLORIDE
CONTOUR WOOD BLOCKS
VISE



DIRECTIONS

- 1. SECURE THE INSTRUMENT FOR REMOVAL OF CAP SCREWS.

 NOTE: THE INSTRUMENT SHOULD NOT BE CLAMPED IN A VISE UNLESS IT IS

 SUPPORTED BETWEEN WOOD BLOCKS THAT FIT THE INSTRUMENT CONTOUR.
- 2. MARK THE CAP RELATIVE TO THE BODY WITH A PEN (FOR RE-ALIGNMENT LATER.)
- 3. LODSEN THE TWELVE CAP SCREWS. REMOVE THE SCREWS AND LOCKWASHERS; AND DISCARD.
- 4. CAREFULLY REMOVE THE CAP
- CLEAN THE SURFACE OF THE DIAPHRAGM USING A SOFT LINT-LESS CLOTH AND METHYLENE CHLORIDE, BEING CAREFUL NOT TO EXERT PRESSURE ON THE DIAPHRAGM.
- 6. CLEAN THE PRESSURE CAP
- 7. REPLACE THE PRESSURE CAP ON THE INSTRUMENT
- 8. ALIGN THE MARKS MADE IN STEP 2.
- 9. LUBRICATE SCREWS WITH A ANTI-GALLING COMPOUND.
- 10. INSTALL NEW SCREWS AND LOCKWASHERS IN CAP.
- 11. LIGHTLY TIGHTEN EACH SCREW AS IN ABOVE DIAGRAM, MAKING CERTAIN CAP IS SITTING EVENLY ON BODY.
- 12. TORQUE SCREWS TO 51 in./lbs. IN SEQUENCE AS INDICATED IN ABOVE DIAGRAM.
- 13. APPLY 3 TIMES RATED FSO PRESSURE TO THE PRESSURE PORT.
- RECALIBRATE